

## **CORRECT CHOICE OF CONSUMABLES FOR METLAM AUSTRALIA DISPENSERS (SOAP, TOILET ROLL & PAPER TOWEL)**

### **METLAM AUSTRALIA DISPENSER GUIDELINES**

As Metlam Australia does not sell consumable products, the products listed below reflect the most popular range of consumables in the market. There are also many product equivalents that can be successfully utilised in Metlam dispensers, use below as a guide to the Metlam suitability requirements. Please note, Metlam recommends that any consumable is trialed prior to being purchased to ensure suitability as manufacturers of products may change dimensions and ingredients without notification to Metlam.

### **GUIDING PRINCIPLE:**

The key to finding the correct products to put in your Metlam Australia dispenser is knowing the width and depth of your product and maximizing the internal space available. **Note:** If the paper is too narrow it may fall out of the dispenser in clumps or if the soap is too thick or thin, it may block the pump or leak through the valve.

### **WHAT TYPE OF SOAP DO I USE IN MY METLAM SOAP DISPENSER?**

Metlam recommends the use of commercially available liquid soap. The soap used in our Stainless Steel Dispensers should preferably:

- Be coconut or vegetable oil based;
- Have a neutral pH (6.5 - 9.0) and;
- Be free from any alcohol, solvents or abrasive particles. The use of these can cause irreparable damage to your dispenser including staining, corrosion, degradation of the plastic and rubber inside the valve and can void your warranty.

The soap used should be viscous and have a thickness between 1,000 and 5,000 CPS (centipoises), bearing in mind that soap viscosity changes dependent on the ambient temperature. A good rule of thumb to follow is that the soap should flow freely at room temperature. Remember, thinner soaps are more likely to leak from your valve and thicker soaps lower the dosing volume.

For Foam Soap Dispensers the Viscosity Range for commercially suitable foam soap should be between 250-2,500 CPS (centipoises).

### **CONSUMABLE SUPPLIERS**

Consumable products for Metlam Dispensers can be purchased from all consumable suppliers, the most commonly known of these include:

- [Caprice Paper](#)
- [John S Hayes](#)
- [Melbourne Cleaning Supplies](#)
- [Officeworks](#)

For further Consumable advice contact your local Metlam Australia Business Development Manager, Regional Sales Manager or contact our Head Office on 1300 METLAM.

# Information Sheet



Metlam Dispenser Code	Dispenser Type	Overall Dimensions (Storage Compartment)	Suitable Products Available
ML600, ML602, ML603, ML605, ML640AS or ML641AS	Commercial Grade Liquid Soap  Viscosity Range: 1,000 - 5,000cps (centipoises)  pH Range: 6.5-9.0	1.2 Litre	<b>Hexa</b> 070101 or 070104 Food Service Soap <b>Regal</b> RSOAP5L, RSOAP15L, RSOAP5WL or RSOAP15WL Lotion Soap
ML606, ML615B		400ml	
ML610		700ml	
ML616-4 or ML616-6		475ml	
ML628-4 or ML628-6		950ml	
ML635		475ml	
ML655 or ML663W		600ml	
ML950DA		950ml	
ML950SS		900ml	
ML275BSM	Facial Tissue	267mmW x 64mmD	<b>Regal</b> FT100/2 Facial Tissue 2ply <b>Tork</b> 2311408 Facial Tissue 2ply
ML681F	Foam Soap	750mL	<b>Supreme Clear</b> 072301 Foam Soap <b>Hexa</b> 070301 Foam Soap
ML681SF	Viscosity Range: 250-2,500cps (centipoises)	1000mL	
HK_MSD_FOAM_DISP		800mL	
HK_ECO73N1_RECESSED or HK_ECO73N1_SM	Folded Towel	257mmW x 106mmD	<b>Enviro~Saver</b> ES162 Hand Towel <b>Regal</b> R164000 or KRT3200 Hand Towel <b>Tork</b> 0184987 or 0148430 Hand Towel
ECLIPSE3IN1_REC_D		265mm W x 80mmD	
ML707		282mmW x 104mmD	
ML710			
ML725			
ML726			
ML840, ML841, ML841DBL, ML842, ML843 or ML862	Jumbo Toilet Roll	Jumbo Rolls up to 108mmW x 300mmL	<b>Enviro~Saver</b> ESJ500 or ESJ300 Jumbo Roll <b>TruSoft</b> JR500/1R or JR300/2R Jumbo Roll <b>Regal</b> VJR300/2 Jumbo Roll
ML4093SS or ML4093W  ML4093SS_LOCKABLE or ML4093W_LOCKABLE	Roll Towel	220mmW x 180mmD	<b>TruSoft</b> TRT100 or TRT80 Roll Towel <b>Tork</b> 2187951 Roll Towel
ML113, ML513, ML225, ML256, ML260, ML261, ML262, ML263, ML267, ML800, ML801, ML820, ML820A, ML825, ML832, ML833, ML835, ML836,	Standard Toilet Roll	-	<b>TruSoft</b> K1R850/4 or 400/2R Toilet Roll <b>Tork</b> 2170329 or 00234 Toilet Roll <b>Enviro~Saver</b>

# Information Sheet



ML837, ML838, ML3355B, DESIGNER_2707 or ML949_375 ML4135 or ML4135_2  ML5856, ML6000, ML6002, ML6004, ML6048, ML6049, ML6050, ML6224, ML6225, ML6226  MLR50TPH or MLR50NCTPH  700_SS_2TH or 700_SS_TRH			ES400 Toilet Roll <b>Regal</b> K2V400 Toilet Roll <b>Standard Toilet Roll</b> Approx. 400 Sheets per roll
ML705	Super Slim / Slimline Folded Towel	265mmW x 70mmD	<b>Enviro™Saver</b> ES150 Interleaved Hand Towel <b>Regal</b> R16150A or KRT2400 Interleaved Hand Towel <b>Tork</b> 0170370 Interleaved Hand Towel <b>Kleenex</b> 4456 Optimum Towel <b>Scott</b> 4455 Optimum Towel or 5855 Compact Towel
ML706		265mmW x 70mmD	
ML727		265mmW x 70mmD	
ML230AD	Auto Air Freshener	900mL Replaceable Commercial Aerosol  <b>NB – Standard domestic aerosol cans are not suitable</b>	<b>Airwick</b> 8141111, 8141113 or 8141115 Auto Air Freshener Refills

The technical recommendations contained in this document are necessarily of a general nature and should not be relied upon for specific applications without first securing competent advice. Whilst Metlam Australia Pty Ltd has taken all reasonable steps to ensure the information contained herein is accurate and current, and in accordance with ASSDA recommendations, it does not warrant the accuracy or completeness of the information and does not accept liability for errors or omissions. Any Commercial product should only be installed by a competent tradesperson and serviced/maintained by knowledgeable janitorial staff or competent people. Metlam Australia accepts no responsibility for any damage to product, walls or fixtures due to incorrect installation or maintenance of any of their products.